



INSTALLATION MANUAL

TRUCK FENDER TOOL BOX

Level of Difficulty

Easy

Parts List*

- | | |
|---|-----------------------|
| 1 | Truck fender tool box |
| 2 | Key |

* Hardware not included. You must purchase your own hardware to install this tool box.

Tools Required

Drill	Drill bit set
Ratchet	Socket set
Tape measure	--

Torque Specifications*

	Metric	SAE	
	M6 bolt		3 ft.-lbs.
	M8 bolt		7 ft.-lbs.
	M10 bolt		16 ft.-lbs.
	M12 bolt		28 ft.-lbs.
	1/4" bolt		3 ft.-lbs.
	5/16" bolt		7 ft.-lbs.
	3/8" bolt		16 ft.-lbs.
	7/16" bolt		20 ft.-lbs.
	1/2" bolt		28 ft.-lbs.

* Above specifications are general guidelines. If purchasing hardware use the torque specifications provided with that hardware.

Maintenance

For polished, gloss and other smooth finishes, polish may be used to clear small scratches and scuffs on the finish.

Mild automotive detergent may be used to clean the product. Do not use dish detergent, abrasive cleaners, abrasive pads, wire brushes or other similar products that may damage the finish.

⚠ DANGER

Danger of explosion. Do not use this product for storing or transporting flammables, explosives, hazardous materials or hazardous waste, such as containers of gasoline, solvents, gun powder, dynamite, propane tanks, acetylene tanks and cutting torches.

⚠ WARNING

Never exceed the vehicle manufacturer's recommended capacity.

This product can reduce the driver's ability to clearly see roadways, vehicular or pedestrian traffic and other objects through the rear and side windows of the vehicle, which may cause an accident. Extra precaution should be taken when driving a vehicle with this product.

Do not interfere with factory-installed safety equipment.

Representative Product Photos (your specific box may vary in style, size or finish)



NOTICE

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

To help prevent damage to the product or vehicle, refer to the torque specifications when securing hardware during the installation process.

Do not use this product for purposes other than those for which they were designed. Never modify this product.

Consult your dealer if you have any questions regarding the installation, operation, use and limits of this product.

Treat or seal all fasteners and exposed metal in any holes drilled in vehicle to prevent corrosion.

Product Registration and Warranty

CURT Group stands behind our products with industry-leading warranties.

Provide feedback and help us to improve our products by registering your purchase at: warranty.curtgroup.com/surveys

Step 1

Remove the bottom two drawers from the tool box and place the tool box on the bed of the truck. Ensure the paddle handle clears the bed rail of the truck and the tool box lid opens properly. A custom shim may need to be placed under the tool box so the handle can be accessed.

Step 2

Locate two desired mounting points on the lip of the bed rail. Ensure there is nothing in the way of drilling or obstructing the tool box from mounting properly. Measure these locations and mark your drill holes on the tool box. Drill 1/4" holes in the tool box in the marked locations.

Locate two desired mounting points on the base of the tool box where the drawers have been removed. Ensure there is nothing in the way of drilling or obstructing the tool box from mounting properly. Drill 1/4" holes in the tool box in the marked locations.

Step 3

WARNING

Before drilling into your truck bed, check under your vehicle to ensure the drill location does not puncture, cut or obstruct any brake or fuel fluid lines, electrical wires, fuel tanks, etc. Precaution must be taken that all fasteners near the fuel tank do not create the possibility of fuel tank puncture or other damage during a collision.

Use the drilled holes in the tool box to mark the lip of the bed rail and the bed of the truck. Remove the tool box and drill 1/4" holes in all marked locations. Align the holes in the tool box with the drilled holes in the bed of the truck and lip of the bed rail.

Insert a minimum of one bolt and flat washer (not provided) through each drilled hole of the tool box and secure with one flat washer and nylock nut (not provided) on the underside of the mounting surface. Do this for each mounting hole.

Tighten all hardware to the recommended torque specifications on page 1.

Re-install the bottom two drawer slides.

Step 4

CAUTION

Ensure all knobs, bolts, screws, straps and locks are firmly secured before every trip. Periodically re-tighten and inspect all components for signs of wear, corrosion and fatigue.

With the truck fender tool box installed, periodic inspections should be performed to ensure all mounting hardware remains tight.

To protect your investment, see the 'Maintenance' section on page 1.

Congratulations on the installation of your new UWS truck fender tool box.

